

PS200 Series

Quick Operation Guide



www.teledynegfd.com

This Quick Operation Guide is NOT a substitute for the Operations & Maintenance Manual which MUST be read and understood, prior to operating, by anyone using or servicing the monitor. Failure to do so may result in serious injury or death.


Quick Config Display



Switch On




Manual Zero



Manual Datalog




Pump



Quick Calibration (Optional)




Alarm Acknowledge




Switch Off




Backlight MAX / MIN / STEL / LTEL




Reset MAX / MIN



Self Test



Zero Fault / Flow Fault



Charging

